



NX-20 INSTRUCTION MANUAL

Charging Procedure:

1. Plug in the AC lead to power on the charger. The status light will flash green, waiting for the battery.
2. Attach the battery to the charger via the Tamiya connector. Press the Start/Stop button once to begin charging (lights will turn red while charging).
Please note: The charging rate is 2A. Please check before charging that this is suitable to the pack you are charging.
3. Once the battery is fully charged (lights will turn solid green for each cell), remove the battery and power off charger.

WARNING:

This charger is not a domestic appliance. It is not for use in the home and should only be positioned in the correct environment.

- ▶ Never leave the charger unattended.
- ▶ Never charge non-approved or non UK / EU compliant batteries.
- ▶ Do not attempt to charge Lithium, or any other battery that is not NiMH or NiCd using this charger.
- ▶ Do not charge near flammable material or items of value.
- ▶ Overlander recommend charging in a safety bag or fireproof box.

Warranty and Service:

We provide a warranty for this product for a period of one year from the date of purchase. In cases where customers can not provide an effective proof of purchase, we will refer to the date of the charger's construction.

Overlander accepts no liability in the case of user disassembly, alteration, or damage caused by improper use.